

Expert Sleepers



User Manual

Revision 1.0

Copyright © 2021 Expert Sleepers Ltd. All rights reserved.

This manual, as well as the hardware described in it, is furnished under licence and may be used or copied only in accordance with the terms of such licence. The content of this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by Expert Sleepers Ltd. Expert Sleepers Ltd assumes no responsibility or liability for any errors or inaccuracies that may appear in this document.

Table of Contents

Introduction.....	4
Installation.....	4
Power requirements.....	4
Inputs and outputs.....	5
Controls.....	5
Calibration.....	5
Where to get help.....	5
Acknowledgments.....	5

Introduction

Congratulations on your purchase of an Expert Sleepers “Ivo”. Please read this user manual before operating your new module.

Ivo is a resonant low-pass VCF (Voltage Controlled Filter), switchable between 2-pole (12dB/octave) and 3-pole (18dB/octave) responses, with voltage control over feedback (resonance) as well as cutoff frequency. It will self-oscillate in 2-pole mode.

The module has two audio inputs, one with an attenuator, so it will also mix two signals at the filter input.

The module is 100% analogue, using discrete transistor OTAs.



Installation

House the module in a Eurorack case of your choosing. The power connector is 16-pin [Doepfer standard](http://www.doepfer.de/a100_man/a100t_e.htm)¹. If using the power cable supplied with the module, the red edge of the cable is closest to the bottom edge of the PCB, and carries -12V. ("-12V" is marked on the PCB itself next to this end of the connector.) Be sure to connect the other end of the power cable correctly, again so -12V corresponds to the red stripe on the cable.

Power requirements

Ivo draws up to 22mA on the +12V rail, and 18mA on the -12V rail.

It does not use the 5V rail.

¹ http://www.doepfer.de/a100_man/a100t_e.htm

Inputs and outputs

Ivo's input and output jack sockets are illuminated, lighting red for positive voltage and blue for negative voltage. (Audio appears purple, since it is a rapid alternation of positive and negative.)

Inputs with attenuators are indicated by a dotted line linking the socket to its corresponding attenuator knob.

From top to bottom, Ivo's sockets are:

- Filter cutoff CV input
- Secondary filter cutoff CV input, with attenuator
- Feedback CV input, with attenuator
- Audio input
- Secondary audio input, with attenuator
- Audio output

The two filter cutoff inputs are summed; similarly the two audio inputs are summed (mixed).


Controls

In addition to the three attenuators, there is a knob for the cutoff frequency (blue) and a knob for the feedback (yellow).

The switch (marked “poles”) selects between 2-pole (12dB/octave) and 3-pole (18dB/octave) filter responses.

Calibration

Ivo's cutoff frequency response is approximately 1 Volt/octave. The exact scaling can be adjusted with a trim pot (“RV6”) on the PCB as shown below:



Where to get help

Email, forum, and social media links can be found at the bottom of every page on [our website](#)².

Acknowledgments

Black and white photography by [Israel Denadai](#)³.

² <https://www.expert-sleepers.co.uk>

³ <http://israeldenadai.com.br/bw>