athrú
Wavefolder

|ˈɑːrˠuː| **verb** (mathematics) an act or process through which something becomes different; to change, transform, alteration, variation and mutation

PRIMARY INPUT

FRONT

OUTPUT

WAVEFOLD DEPTH
(EXPONENTIAL RESPONSE FADER CONTROL)

CV ATTENUVERTER

CV INPUT

SYMMETRY BIAS / EXTERNAL INPUT

ENGAGING BIAS SWITCH DISABLES ATTENUVERTER. SIGNAL SUMS AT UNITY GAIN WITH PRIMARY SIGNAL. POT BECOMES A MANUALLY CONTROLLED BIAS.

EXTERNAL SIGNAL INPUT WITH ATTENUVERTER. SUMS WITH PRIMARY SIGNAL AFTER FADER.

DECAY ENVELOPE

STRIKE
STRIKE INPUT TRIGGERS A DECAY ENVELOPE THAT OPENS THE VCA. GREAT FOR CREATING PERCUSSIVE AND PLUCKED SOUNDS.

DRIVE
DRIVE TOGGLE CAN BE ENGAGED TO TAKE THINGS UP A GEAR, OPENING UP FURTHER WORLDS OF DISTORTED HARMONICS AND WAVEFOLDING.

'STRIKE DECAY' SETS DECAY TIME OF STRIKE ENVELOPE

BACK

INSTRUō | SPECIALIST SYNTHESIZERS

Strike Decay

DRIVE

DRIVE